

User Manual ► FEISOL Video Head VH-40 User Manual

The handle of the VH-40 video head was detached for shipping. After unpacking the VH-40 video head, loosen the locking knob of the Quick Release Clamp and remove the black tube; two M4 screws can be found underneath the knob. Place the handle inside the handle base clamp and use the enclosed Allen key to tighten the counter-sunk screws (to lock the handle at the desired angle). Then re-attach the black tube and the quick release plate's locking knob to complete the handle assembly.

