

User Manual ► FEISOL Bicycle Mount

A. User Instructions

The bike mount is shipped un-assembled - please use the following instructions for assembling:

First, use the enclosed 3mm hexagonal wrench to attach the mount bracket on the bike handle bar. Do not screw in tightly yet. Then, use the enclosed 2.5mm hexagonal wrench to lock the mounting platform onto the bracket tightly, as shown in photo #1. Adjust the bracket angle (camera angle) to the desired position, and then tighten all the screws to fix bike mount into place.

First, use the enclosed 3mm hexagonal wrench to attach the mount bracket on the bike handle bar. Do not screw in tightly yet. Then, use the enclosed 2.5mm hexagonal wrench to lock the mounting platform onto the bracket tightly, as shown in photo #1. Adjust the bracket angle (camera angle) to the desired angle, and then tighten all the screws to fix bike mount into place.



B. Further Instructions:

If mounting a larger camera or a camera/lens combination, you should first attach a ball head to the mounting platform.



Attention:

1. **Safety first!** It is not recommended that you take photos while riding your bicycle.
2. This bike mount is recommended for smooth road surfaces only. Using it on rough surfaces may damage your photographic equipment.
3. For use with a video camera, please avoid hard drive and DVD type video cameras; surface-vibration may cause the video camera to malfunction.